

Packet Tracer - Configure ASA Basic Settings and Firewall Using the CLI

Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
R1	G0/0	209.165.200.225	255.255.255.248	N/A
	S0/0/0 (DCE)	10.1.1.1	255.255.255.252	
R2	S0/0/0	10.1.1.2	255.255.255.252	N/A
	S0/0/1 (DCE)	10.2.2.2	255.255.255.252	
R3	G0/1	172.16.3.1	255.255.255.0	N/A
	S0/0/1	10.2.2.1	255.255.255.252	
ASA	G1/1	209.165.200.226	255.255.255.248	NA
	G1/2	192.168.1.1	255.255.255.0	
	G1/3	192.168.2.1	255.255.255.0	
DMZ Server	NIC	192.168.2.3	255.255.255.0	192.168.2.1
PC-B	NIC	192.168.1.3	255.255.255.0	192.168.1.1
PC-C	NIC	172.16.3.3	255.255.255.0	172.16.3.1

Objectives

- Verify connectivity and explore the ASA
- Configure basic ASA settings and interface security levels using CLI
- Configure routing, address translation, and inspection policy using CLI
- Configure DHCP, AAA, and SSH
- Configure a DMZ, Static NAT, and ACLs

Scenario

Your company has one location connected to an ISP. R1 represents a CPE device managed by the ISP. R2 represents an intermediate Internet router. R3 represents an ISP that connects an administrator from a network management company, who has been hired to remotely manage your network. The ASA is an edge CPE security device that connects the internal corporate network and DMZ to the ISP while providing NAT and DHCP services to inside hosts. The ASA will be configured for management by an administrator on the internal network and by the remote administrator. The ISP assigned the public IP address space of 209.165.200.224/29, which will be used for address translation on the ASA.

All router and switch devices have been preconfigured with the following:

- Enable password: **ciscoenpa55**
- Console password: **ciscoconpa55**

- Admin username and password: **admin/adminpa55**

Note: This Packet Tracer activity is not a substitute for the ASA labs. This activity provides additional practice and simulates most of the ASA 5506-X configurations. When compared to a physical ASA 5506-X, there may be slight differences in command output or commands that are not yet supported in Packet Tracer.

Instructions

Part 1: Verify Connectivity and Explore the ASA

Step 1: Verify connectivity.

The ASA is not currently configured. However, all routers, PCs, and the DMZ server are configured. Verify that PC-C can ping any router interface. PC-C is unable to ping the ASA, PC-B, or the DMZ server.

Step 2: Determine the ASA version, interfaces, and license.

Use the **show version** command to determine various aspects of this ASA device.

Step 3: Determine the file system and contents of flash memory.

- Enter privileged EXEC mode. A password has not been set. Press **Enter** when prompted for a password.
- Use the **show file system** command to display the ASA file system and determine which prefixes are supported.
- Use the **show flash:** or **show disk0:** command to display the contents of flash memory.

Part 2: Configure ASA Settings and Interface Security Using the CLI

Tip: Many ASA CLI commands are similar to, if not the same, as those used with the Cisco IOS CLI. In addition, the process of moving between configuration modes and submodes is essentially the same.

Step 1: Configure the hostname and domain name.

- Configure the ASA hostname as **NETSEC-ASA**.
- Configure the domain name as **netsec.com**.

Step 2: Configure the enable mode password.

Use the **enable password** command to change the privileged EXEC mode password to **ciscoenpa55**.

Step 3: Set the date and time.

Use the **clock set** command to manually set the date and time (this step is not scored).

Step 4: Configure the INSIDE and OUTSIDE interfaces.

You will only configure the G1/1 (OUTSIDE) and G1/2 (INSIDE) interfaces at this time. The G1/3 (DMZ) interface will be configured in Part 5 of the activity.

- Create the G1/1 interface for the outside network (209.165.200.224/29), set the security level to the lowest setting of 0, and enable the interface.

```
NETSEC-ASA(config-if) # interface g1/1
NETSEC-ASA(config-if) # nameif OUTSIDE
NETSEC-ASA(config-if) # ip address 209.165.200.226 255.255.255.248
NETSEC-ASA(config-if) # security-level 0
NETSEC-ASA(config-if) # no shutdown
```

- b. Configure the G1/2 interface for the inside network (192.168.1.0/24) and set the security level to the highest setting of 100 and enable the interface.

```
NETSEC-ASA(config)# interface g1/2
NETSEC-ASA(config-if)# nameif INSIDE
NETSEC-ASA(config-if)# ip address 192.168.1.1 255.255.255.0
NETSEC-ASA(config-if)# security-level 100
NETSEC-ASA(config-if)# no shutdown
```

- c. Use the following verification commands to check your configurations:

- 1) Use the **show interface ip brief** command to display the status for all ASA interfaces.

Note: This command is different from the IOS command **show ip interface brief**. If any of the physical or logical interfaces previously configured are not up/up, troubleshoot as necessary before continuing.

Tip: Most ASA **show** commands, including **ping**, **copy**, and others, can be issued from within any configuration mode prompt without the **do** command.

- 2) Use the **show ip address** command to display the interface information.

Step 5: Test connectivity to the ASA.

- a. You should be able to ping from PC-B to the ASA inside interface address (192.168.1.1). If the pings fail, troubleshoot the configuration as necessary.
- b. From PC-B, ping the G1/1 (OUTSIDE) interface at IP address 209.165.200.226. You should not be able to ping this address.

Part 3: Configure Routing, Address Translation, and Inspection Policy Using the CLI

Step 1: Configure a static default route for the ASA.

Configure a default static route on the ASA OUTSIDE interface to enable the ASA to reach external networks.

- a. Create a “quad zero” default route using the **route** command, associate it with the ASA OUTSIDE interface, and point to the R1 G0/0 IP address (209.165.200.225) as the gateway of last resort.

```
NETSEC-ASA(config)# route OUTSIDE 0.0.0.0 0.0.0.0 209.165.200.225
```

- b. Issue the **show route** command to verify the static default route is in the ASA routing table.
- c. Verify that the ASA can ping the R1 S0/0/0 IP address 10.1.1.1. If the ping is unsuccessful, troubleshoot as necessary.

Step 2: Configure address translation using PAT and network objects.

- a. Create network object **INSIDE-NET** and assign attributes to it using the **subnet** and **nat** commands.

```
NETSEC-ASA(config)# object network INSIDE-NET
NETSEC-ASA(config-network-object)# subnet 192.168.1.0 255.255.255.0
NETSEC-ASA(config-network-object)# nat (INSIDE,OUTSIDE) dynamic interface
NETSEC-ASA(config-network-object)# exit
```

- b. The ASA splits the configuration into the object portion that defines the network to be translated and the actual **nat** command parameters. These appear in two different places in the running configuration. Display the NAT object configuration using the **show run** command.
- c. From PC-B attempt to ping the R1 G0/0 interface at IP address 209.165.200.225. The pings should fail.

- d. Issue the **show nat** command on the ASA to see the translated and untranslated hits. Notice that, of the pings from PC-B, four were translated and four were not. The outgoing pings (echos) were translated and sent to the destination. The returning echo replies were blocked by the firewall policy.

Part 4: Configure DHCP, AAA, and SSH

Step 1: Configure the ASA as a DHCP server.

- a. Configure a DHCP address pool and enable it on the ASA INSIDE interface.

```
NETSEC-ASA(config)# dhcpd address 192.168.1.5-192.168.1.36 INSIDE
```
- b. (Optional) Specify the IP address of the DNS server to be given to clients.

```
NETSEC-ASA(config)# dhcpd dns 209.165.201.2 interface INSIDE
```
- c. Enable the DHCP daemon within the ASA to listen for DHCP client requests on the enabled interface (INSIDE).

```
NETSEC-ASA(config)# dhcpd enable INSIDE
```
- d. Change PC-B from a static IP address to a DHCP client and verify that it receives IP addressing information. Troubleshoot, as necessary to resolve any problems.

Step 2: Configure AAA to use the local database for authentication.

- a. Define a local user named **admin** by entering the **username** command. Specify a password of **adminpa55**.

```
NETSEC-ASA(config)# username admin password adminpa55
```
- b. Configure AAA to use the local ASA database for SSH user authentication.

```
NETSEC-ASA(config)# aaa authentication ssh console LOCAL
```

Step 3: Configure remote access to the ASA.

The ASA can be configured to accept connections from a single host or a range of hosts on the INSIDE or OUTSIDE network. In this step, hosts from the OUTSIDE network can only use SSH to communicate with the ASA. SSH sessions can be used to access the ASA from the inside network.

- a. Generate an RSA key pair, which is required to support SSH connections. Because the ASA device has RSA keys already in place, enter **no** when prompted to replace them.

```
NETSEC-ASA(config)# crypto key generate rsa modulus 1024
```

```
WARNING: You have a RSA keypair already defined named <Default-RSA-Key>.
```

```
Do you really want to replace them? [yes/no]: no
```

```
ERROR: Failed to create new RSA keys named <Default-RSA-Key>
```
- b. Configure the ASA to allow SSH connections from any host on the INSIDE network (192.168.1.0/24) and from the remote management host at the branch office (172.16.3.3) on the OUTSIDE network. Set the SSH timeout to 10 minutes (the default is 5 minutes).

```
NETSEC-ASA(config)# ssh 192.168.1.0 255.255.255.0 INSIDE
```

```
NETSEC-ASA(config)# ssh 172.16.3.3 255.255.255.255 OUTSIDE
```

```
NETSEC-ASA(config)# ssh timeout 10
```
- c. Establish an SSH session from PC-C to the ASA (209.165.200.226). Troubleshoot if it is not successful.

```
C:\> ssh -l admin 209.165.200.226
```
- d. Establish an SSH session from PC-B to the ASA (192.168.1.1). Troubleshoot if it is not successful.

```
C:\> ssh -l admin 192.168.1.1
```

Part 5: Configure a DMZ, Static NAT, and ACLs

R1 G0/0 and the ASA OUTSIDE interface already use 209.165.200.225 and .226, respectively. You will use public address 209.165.200.227 and static NAT to provide address translation access to the server.

Step 1: Configure the DMZ interface VLAN 3 on the ASA.

- a. Configure DMZ VLAN 3, which is where the public access web server will reside. Assign it IP address 192.168.2.1/24, name it **DMZ**, and assign it a security level of 70. Because the server does not need to initiate communication with the inside users, disable forwarding to interface VLAN 1.

```
NETSEC-ASA(config)# interface g1/3
NETSEC-ASA(config-if)# ip address 192.168.2.1 255.255.255.0
NETSEC-ASA(config-if)# nameif DMZ
INFO: Security level for "DMZ" set to 0 by default.
NETSEC-ASA(config-if)# security-level 70
NETSEC-ASA(config-if)# no shutdown
```

- b. Use the following verification commands to check your configurations:

Use the **show interface ip brief** command to display the status for the ASA interfaces.

Use the **show ip address** command to display the information for the ASA interfaces.

Step 2: Configure static NAT to the DMZ server using a network object.

Configure a network object named **DMZ-SERVER** and assign it the static IP address of the DMZ server (192.168.2.3). While in object definition mode, use the **nat** command to specify that this object is used to translate a DMZ address to an OUTSIDE address using static NAT, and specify a public translated address of 209.165.200.227.

```
NETSEC-ASA(config)# object network DMZ-SERVER
NETSEC-ASA(config-network-object)# host 192.168.2.3
NETSEC-ASA(config-network-object)# nat (DMZ,OUTSIDE) static 209.165.200.227
NETSEC-ASA(config-network-object)# exit
```

Step 3: Configure an ACL to allow access to the DMZ server from the Internet.

Configure a named access list **OUTSIDE-DMZ** that permits the TCP protocol on port 80 from any external host to the internal IP address of the DMZ server. Apply the access list to the ASA OUTSIDE interface in the "IN" direction.

```
NETSEC-ASA(config)# access-list OUTSIDE-DMZ permit icmp any host 192.168.2.3
NETSEC-ASA(config)# access-list OUTSIDE-DMZ permit tcp any host 192.168.2.3
eq 80
NETSEC-ASA(config)# access-group OUTSIDE-DMZ in interface OUTSIDE
```

Note: Unlike IOS ACLs, the ASA ACL permit statement must permit access to the internal private DMZ address. External hosts access the server using its public static NAT address, the ASA translates it to the internal host IP address, and then applies the ACL.

Step 4: Test access to the DMZ server.

From a web browser on PC-C, navigate to the DMZ server (209.165.200.227). Troubleshoot if it is not successful.